TSA *see* The Survey Association
tunnel alignment by laser 540
two-level cross-section 740
two-peg test for levelling 43
  worked example 44

uncooperative target 135
underground detail 403
underground services 455–9
  Electro Magnetic Locators (EML) 456
  further reading and sources of information 461
  Ground Penetrating/Probing Radar (GPR) 457
  Radio Frequency Location (RFL) devices 456
  recording buried assets 457
United States Department of Defense (DoD) 249
units 783
universal constant 128
universal lasers 545
urban canyons 284
user segment 252

variance 353
  propagation of 361
  reference variance 360
VDOP 263
vector model 438
vellum 395
velocity (in GNSS) 315
vertical alignment 648, 684
  in sectioning 730
  phasing with horizontal alignment 652, 696
vertical angle 66, 67, 174, 177
  measurement of 86, 174, 177
vertical axis 70
  effect of an inclined 92, 95, 164
vertical circle 72, 144
  error 93, 165
  index 72, 93, 165
  orientation of 495
vertical clamp 72, 144
vertical collimation 88, 165
  error 93, 94, 165
vertical control 8, 183, 480–91
vertical curves 683–714
  adequate visibility on 686
  assumptions made in the calculation of 688
  calculating reduced levels along 690
  computer-aided design of 701
  defining using machine control systems 703
  defining using sight rails 702
  designing 698
  equation of 688
  exercises 712–14
  further reading and sources of information 714
  geometry of 687
  gradients 684
  highest/lowest point of 691
  K values 694
  length of 692, 696
  need for 684
  parabolic 687
  passenger comfort and safety on 686
  phasing of horizontal and vertical alignments 696
  purposes of 686
  setting out 702
  sight distances 693
  worked examples 703–11
vertical distance 103
vertical interval (contour interval) 415
verticality *see* controlling verticality in structures
Virtual Reference Station (VRS) 283
visible beam lasers 529
visualisation 6, 10, 655
volume of uncertainty 273
volumes and their calculation
  end areas method 746
  exercises 776
  formulae for various solids 787
  from contours 756
  from cross-sections 739–56
  from spot heights 757
  further reading and sources of information 779
  prismoidal formula 747
  road curvature effect on 748
  units 717
  worked examples 750, 753, 757, 759, 766, 770
VRS *see* Virtual Reference Station

WAAS *see* Wide Area Augmentation System
walking the site 471
waste 765
wavelength 128
weather conditions
  effect on angle measurement 97
  effect on levelling 55
weight 358
weighted mean 358
well-conditioned triangles 230, 233
WGS84 *see* World Geodetic System 1984
whole-circle bearing 186, 205
wholly transitional curve 627
  design method for 650
  length of 647
  setting out 656
Wide Area Augmentation System (WAAS) 271, 413
Windows CE operating system 13, 155
wireframe view 434
wireless communication 162
working drawings 468
working from the whole to the part 237, 239, 472, 475, 481, 527
Works 464
World Geodetic System 1984 (WGS84) 293, 308, 314
World Geodetic System 84 broadcast TRF 314

Y code 253

zenith angle 67, 173, 177
  measurement of 86, 173, 177
zero (in angle measurement) 86
zero chainage 593, 728
zero error in a levelling staff 54
zero error in EDM 166
zero height 307
zero point errors 164–5
ZERO SET (0 SET) key 73, 86, 90